



# FOLDING A-FRAMES

## SET UP

1



Remove from bag and shake out. The A-frame will pop up. Be careful if erecting this in a confined space.



2



Fasten the two stays on either side.

## TAKE DOWN

1



Holding the A-frame in a vertical position, stand to one side.

2



Hold at the top. Press the centre until the banner folds.

3



Pull both edges towards the centre. The top will fold forwards and down.

4



Hold the top and fold under and back. The sides will collapse under each other.

5



Store away in the bag.

## CARING FOR YOUR BANNER

- Always fasten the stays.
- Ensure the A-frame is stable on the ground when set up. Use the pockets to weigh it down.
- Do not fold the A-Frame on concrete or rough surfaces as this will rub on the band.
- Do not force the fold, check the instructions.
- Clean with warm soapy water.
- Always dry thoroughly before folding and packing away.