



FLYING BANNERS

SET UP



1

Assemble the tapered rod section making sure they fit flushly together.



2

Insert the rod into the sleeve. Push the rod all the way to the end of the sleeve.



3

Ensure the tip of the rod is pushed right to the end of the sleeve.



4

Hook the cord over the base.
If the banner is too tight or too loose adjust the cord and cleat.



5

To insert the banner into the base ensure the ring on the Quick Connect is **up**.
Insert the rod and push the ring **down** to lock it in place.



CARING FOR YOUR BANNER

When inserting the rod push it to the end of the sleeve to avoid the top chaffing against the fabric.



Ensure the rods are flush fitting for extra durability.

Ensure the banner has even tension by adjusting the cord and cleat at the base.

Erect the banner in an area big enough for 360° rotation so it doesn't rub against walls, plants, street signs etc.

Use the correct hardware for the correct surface, for example a Stake for snow or sand, a Universal base on tiles or carpets.

When using a ground stake ensure the ground is clear of any obstacles such as pipes and rocks.

Take care when hitting the stake into the ground ensure you do not hit the spindle.



Before putting up the banner ensure it will be clear of overhead electrical cables when standing at its full height.

Clean with warm, soapy water.

Dry thoroughly before packing away.

To increase the life-span of your banner take down at night or in winds exceeding 25 knots. Remember, colour lasts longer in the shade.